



TEAKSEAL COLOUR PROTECTOR

Revision: 01/2011

Page 1 of 1

Product:

TeakSeal Teak Colour Protector is a teak coloured preservative impregnator with mould inhibitors. Colour Protector does not contain any oils, solvents, silicone. This product is ideally suited to both new and existing decks to maintain or restore that just sanded appearance. Colour Protector is easy to use. To a dry deck; Apply a small amount of protector to the cloth provided and rub into the deck planks working the colour protector into the teak. Work a few planks at a time for their entire length to avoid cross hatching. We recommend cleaning with TeakSeal Teak Cleaner prior to application.

Deck Cleaning:

We do recommend: TeakSeal Teak Cleaner for your deck as it has been designed not to harm your deck or the deck caulking.

TeakSeal products do not contain aggressive chemicals cleaners and are 100% biodegradable. They do not contain any corrosive agents and are not harmful to you, your deck or any part of your boat. Teak Cleaner can also be used for cleaning the entire boat once diluted. TeakSeal does not contain any oil, silicone or wax.

We do not recommend: Do not use 2 part cleaners (cleaner and brightener) as they are too aggressive.

- A. The cleaner component of a 2-part system can contain a high pH Alkali cleaner containing chemicals such as, but not limited to sodium hydroxide, caustic soda, and ingredients used in the manufacture of bleaches and drain cleaners. Packing will often carry a warning “corrosive wear gloves”
- B. The brightener component of a 2 part can contain a low pH (strong acid) such as, but not limited to hydrochloric acid, phosphoric acid and oxalic acid. These acids are commonly found in concrete and brickwork cleaners; their misuse will cause irreparable damage to your deck.

These types of cleaners and brighteners are bad for our waterways and their inhabitants. If these types of cleaning systems are used they must be applied in strict accordance with the manufacturers recommendations. Never use chemicals on your deck that have not been designed for the purpose. Clothes washing powders and liquids, mould cleaners, pool chlorine, household cleaners and other non-marine deck cleaners should never be used to clean your deck.

Information about deck cleaning can be found on our website under “Teak Deck Cleaning Guide”



Note: The contents contained in this documentation are the result of our experiments and our experience and have been submitted in good faith. Because of the diversity of the materials and substrates and the real number of possible applications which are out of our control we cannot accept any responsibility for the results obtained. In every case it is recommended to carry out preliminary experiments and compatibility tests.

Fixtech Pty Ltd. PO Box 568, Southport, Qld 4215. Tel: +61 (0)7 5530 1099. Fax: +61 (0)7 5530 1322

Email: info@fixtech.com.au

Web: www.fixtech.com.au